



## Fitting instructions

Batwing® seals



**LAS 1212**  
Batwing®



**LAS 1515**  
Batwing®

## Tools required

Tape measure  
Pencil or marker  
Scissors

For further information about our products please visit our website

[www.lorientgroup.com](http://www.lorientgroup.com)

t: +61 (02) 9907 6221  
f: +61 (02) 9907 6152  
e: [admin@lorientau.com.au](mailto:admin@lorientau.com.au)

## Instructions

**Please note:** Batwing® needs to have a 3mm maximum gap between the door and the door stop to enable the door to close. Excessively tight gaps may dislodge the seal from its position and cause the door to bind.

*It is essential to ensure that freshly painted surfaces are fully dry and cured before commencing installation.*

1. Remove Batwing® from packaging and trim to length using scissors.
2. Peel adhesive from both legs of the Batwing® approx 100mm.
3. Mount in the top corner, using a jointing method as tight as possible to ensure continuity of seal.

**Please note:** Recommendations as to methods, use of materials and construction details are based on the experience and knowledge of Lorient and are given in good faith as a general guide and service to designers, contractors and manufacturers.

*Lorient reserves the right to make alterations or delete installation detail without prior notice.*

4. Run finger down centre of the profile pushing it into the centre of the reveal.
5. Pull adhesive backing strips off both legs a little at a time, progressively pushing Batwing® into place.



## Important

The product will not adhere to surfaces where silicone sealant has been applied or where non-stick nano technology anti-graffiti paint has been used.

## Other Lorient products:

Acoustic, smoke & fire seals  
Fire resistant glazing systems  
Fire resistant door hardware  
Air transfer grilles/ dampers